


OEL Disassembly Drawing


ML5520eco/ML5521eco

Revision 1


Printer General Assy




Upper Cover Assy




Printer Unit



Carriage Assy




POW Assy



Option Spare Parts

[Pull-Tractor]



[Bottom-Tractor]

